



# Xerox® VersaLink® C400 Family



**Total width:** 19 in (491 mm) **Total height:** 15 in (399 mm) **Total depth:** 19 in (488 mm)

Dimensions shown are approximate. Please refer to the Installation Guide for exact dimensions

## VersaLink C400

Xerox® VersaLink® C400 Color Printer, Print Letter/Legal, Up To 36ppm (35ppm A4), 2-Sided Print, USB/Ethernet, 550-Sheet Tray, 150-Sheet Multi-Purpose Tray



Once you have used the Product Explorer to configure your product, this QR code will allow you, or a sales person, to easily retrieve your configured product details.

#### How to use your QR Code

1. Open the QR Code reader on your phone, or download a QR code scanning app from your device's app store.
2. Hold your smartphone over the QR Code so that you can clearly see the image within your screen.
3. Your smartphone reads the code and navigates to the intended destination.



Created on 10/5/2018 10:54:45 AM